


# 3.7V Rechargeable Li-ion Battery Only (Type 14500, AA Size)



Connect Either J2 or J3 to CPU Board  
Insert board into SEL\SLU Module  
For 5016743\5416744 installation:

Connect J2 to CPU board  
Connect SEL\SLU Module to J3  
Other installations:

